

Testing a Unis CO2 Release Kit

These are the instructions on how to test the power supply of the Unis CO2 Release kit.



To begin with open the box and check all parts are there. There should be:

1x pressure gauge



1x control box and solenoid valve



You will need to fix the solenoid to the pressure gauge making sure it's the right way round and it all lines up.



Like so



The little screw in the bottom will need to be tightened



Then all you do is plug in to the mains and flick the switch.

As you flick the switch you will hear the solenoid valve click in to place and a red and green light will light up on the control box.



The red light will go out after a second and you will be left with just the green light that stays on.



As long as the lights come on and the solenoid clicks in to place it should mean it is all working.

For more information on hydroponics, Ventilation, CO2 and other technical information please visit our information page [found here](#).

If you have any plant health questions or for any other advice please feel free to call one of our stores today or visit www.3ch.co.uk